

# PIG® Fuel Station Spill Kit in Wall-Mount Cabinet

## Mounting Instructions

1. Mark mounting holes on backside of cabinet using included template. Tape template to back of cabinet prior to drilling. See illustration below for mounting location of template. Align template with top edge of cabinet, drill holes in rear of cabinet using a minimum of a ¼" drill bit.
2. Once all holes are drilled into cabinet, place cabinet against mounting surface and mark one upper hole on surface. Remove cabinet and drill hole.
3. Replace cabinet and secure cabinet to mounting surface using the drilled hole. Make sure cabinet is level. Once it is level mark all other remaining holes and drill.
4. Finish mounting cabinet to surface.

**NOTE:** Hardware not included.

Align template with top edge of cabinet.

