

# PIG Build-A-Berm Bladder Barrier

## Instructions

### Installation

1. Clean floor of any debris or oil. Fill any cracks with caulking. Note that **bladder deployment requires an obstruction-free area of 66" x 58"**.
2. Apply two continuous beads of caulking on the bottom of the Bladder Barrier approximately 1" in from sides and ends and along the entire length. (fig. A)
3. With the dust flap closed and facing out, place the Bladder Barrier in position and carefully apply pressure on the opposing sides along its entire length to seal it to the floor. On uneven or rough surfaces, more sealant and pressure may be needed. (fig. B)

**CAUTION:** To avoid damage, do not apply excessive pressure to the top or sides of the Bladder Barrier structure.

4. Attach the ends of the Bladder Barrier to the adjoining sections of the Build-A-Berm Barrier, applying vinyl cement to the vinyl cover and berm ends. Mold the vinyl cover over the berm ends and hold in place approximately 30 seconds. (fig. C)
5. When the Bladder Barrier is firmly affixed to the floor and berm, lift the dust flap and snip the two rubber bands, leaving them in place. **The bladder itself must not be cut during this process.** (fig. D) Be sure to also detach and discard the "attention" tag without unrolling the bladder. Then lower the dust flap back over the barrier.

Completed installation is shown in (fig. E).

### Bladder Replacement

1. When the containment area has been pumped out, drain the full bladder by raising the outermost corners of the bladder, allowing fluid to flow from the bladder into the containment area. Continue to pump out the containment area. When the containment area is emptied, the replacement bladder can be installed.
2. To install a replacement bladder (PAK525), turn the threaded knob clockwise, lift the dust flap and carefully remove the used bladder.
3. Insert the rolled replacement bladder into the Build-A-Berm Barrier with the Top 5 label facing up. Fit one washer over the threaded nozzle, slide the nozzle through the aperture in the barrier, and fit the other washer over the nozzle. Install nut and turn counterclockwise until tightened. Snip the rubber bands, leaving them in place, before use. **Take care to not cut the bladder during this process.**

**CAUTION: DO NOT** step on or drive over any section of the Bladder Barrier.



**New Pig**

One Pork Avenue  
Tipton, PA 16684-0304

[newpig.com](http://newpig.com)

North America: **1-800-468-4647**

Europe: **+31 (0)76 596 92 50**

PIG, PIG logo are registered trademarks in USA and other countries. See [tm.newpig.com](http://tm.newpig.com)

UK: **0800 919 900**

Outside North America: **+1-814-684-0101**

501871 / 310784