

# PIG Trough Style Roof Leak Diverter

## Drain Assembly Instructions

1. Identify clear drain fitting located in the middle of the unit. The fitting is shipped in the inverted position, with threads on the interior. **(fig. A)**
2. Insert your finger into the center of the drain fitting and pull through, so the threads are on the outside. **(fig. B)**
3. Locate included hose fitting and attach a 3/4" drainage hose (not included). We recommend using TLS174, our reinforced clear drainage hose. **(fig. C)**
4. Insert the male end of the hose assembly (hose connector and drainage hose) into the female end of the drain fitting. Secure it by tightening the ring. **(fig. D)**

**NOTE:** Depending on your application, it may be easier to perform Step 4 after hanging your Leak Diverter.

## Hanging Instructions

1. Identify the structure from which you'll hang the Leak Diverter.
2. Insert PVC rods into pockets along each side of the diverter. **(fig. E)**
3. Feed hanging straps (not included) through grommets, one at a time, as you hang each corner.
4. Hang the diverter as level as possible to create the proper drainage. **(fig. F)**
5. Attach hose assembly (if not already done above) and position hose into a drain or container.

