# **PIG Outdoor Decks**

### **Instructions**

#### **Step 1** — Remove Grates and Absorbents

Remove any grates and absorbent bundles behind the %6"Dia. holes to be used to attach the Outdoor Decks together.

# Step 2 — Align Holes

Align %6"Dia. holes in each Outdoor Deck to be attached.

## Step 3 — Place First Washer

Place flat washer (2) over the hex bolt (1) and insert through mating holes.

## Step 4 — Place Second Washer

Place second flat washer (2) and hex nut (3) on the threaded end of the hex bolt (1). DO NOT TIGHTEN until all Outdoor Decks in the configuration have been assembled.

# Step 5 — Align Deck Edges

Align edges of Outdoor Decks and tighten.

# **Step 6** — **Replace Grates and Absorbents**

Replace any grates and absorbent bundles.

### Step 7 — Attach Drip Channel

Snap the drip T-channel (4) in the slots between the Outdoor Decks.

NOTE: The drip T-channel (4), may need to be cut to properly fit some configurations

				9
t (1). bled.	1	4	3	

ITEM	DESCRIPTION	FLT510 QUANTITY	FLT511 QUANTITY	FLT512 QUANTITY
1	³/16"-16 UNC x 1.5" BOLT	1	2	2
2	¾" x 1.5" FLAT WASHER	2	4	4
3	3/8"-16 UNC HEX NUT	1	2	2
4	DRIP T-CHANNEL	1	2	2



newpig.com

North America: **1-800-468-4647** Europe: **+31 (0)76 596 92 50**  UK: **0800 919 900** 

Outside North America: +1-814-684-0101