

PIG Latching Drum Lid for Poly Drum

Instructions

Depending on which 30-gallon poly drum you have, spacers may be needed for the lid to fit securely. Refer to the list below to determine if a spacer is required for your drum. One set of interchangeable drum spacers are included.

No Spacer

PIG DRM386

Eagle — 1601MB

Grief — 030MB

Spacer

Grief 0530

Mauser M5123

Step 1 — Prepare lid for installation

Remove the hairpin and hinge pin from the hinge bracket (fig. A). Place the lid aside.

Step 2 — Attach spacer

Refer to above chart to determine if a spacer is required for your drum. If no spacer is required, proceed to step 3. Bolt spacer to the retaining ring (fig. B).

Step 3 — Attach retaining ring

Open the clamp lever on retaining ring and place ring over the drum top. Close the lever and make sure the retaining ring is against the bottom edge of the drum rim (fig. C).

Step 4 — Attach lid

Place the drum lid on top of the drum and replace the hinge pin and hairpin (fig. D).

Step 5 — Test lid closure

When the lid is closed and latched, the latch bar should contact the middle of the flat surface on the latch finger. If it does not, adjust the latch bar. Note: The latch finger may not be centered on the latch bar, but that is normal and will not affect lid seal.

To adjust the latch bar, open the lid, then loosen the hex bolt on each side of the latch bar using a $\frac{3}{8}$ " wrench (fig. E). Slide the latch bar as needed, secure the hex bolts and retest the lid closure.



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: 1-800-468-4647

Europe: +31 (0)76 596 92 50

PIG, PIG logo are registered trademarks in USA and other countries. See tm.newpig.com

UK: 0800 919 900

Outside North America: +1-814-684-0101

502193 / 331017