

PPE Disposal Bin

Assembly Instructions



1. Place printed container base upside down and pull open until corners are square.



2. Push slotted flaps inward until they meet, then push tabbed flaps down and insert into slots.



3. Place lid on flat surface. Fold corner tabs down on both ends, then fold long sides inward along score lines until corner tabs face each other.



4. Sink corner tabs into slots and hold in place while folding end flap over top.



5. Insert tabs on end flap into slots and press firmly until "locked" in place. Repeat steps 4 and 5 on opposite end.



6. Stand container base upright and store extra liners in bottom of unit. Insert open liner into container and tuck material into slots near top to hold in place. Place lid for additional support of liner as PPE waste is collected.



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: **1-800-468-4647**

Europe: **+31 (0)76 596 92 50**

China: **+86-21-400 921 5178**

PIG, PIG logo are registered trademarks in USA and other countries. See tm.newpig.com

UK: **0800 919 900**

Outside North America: **+1-814-684-0101**

502902/360962