



SPILL RESPONSE:

DECONTAMINATION

March 2017

CONTENTS FOR ASSEMBLY INSTRUCTIONS

- Kappler Warranty
- Zytron® 500 Decontamination Shower Unit
- [PIG Pump Selection Guide](#)



SPILL RESPONSE: DECONTAMINATION

KAPPLER WARRANTY

It is the responsibility of the user to select suits and other products (“Products”) which are appropriate for each intended use and which meet all legal, regulatory and health standards. Kappler is available to consult on any proposed use.

For a period of 90 days after the date of invoice of any Product purchased by an authorized Kappler Distributor, Kappler warrants all Products to be free from defects in materials and workmanship. This Warranty shall not apply to damage or injury resulting from accident, misuse or neglect, or from alteration of any Product. It is the responsibility of the user to use reasonable care in the maintenance, operation and storage of all Kappler Products.

The sole and exclusive remedy of the purchaser and all users, and the limit of Kappler’s liability for any and all losses, injuries or damages relating to Kappler-manufactured Products, shall be, at Kappler’s option, the refund of the purchase price or the replacement or repair of any Product found to be defective, so long as a claim for warranty adjustment is made by the user within 90 days of the date the Product was invoiced to a Kappler authorized distributor.

In no event shall Kappler be liable for any SPECIAL, INCIDENTAL, or CONSEQUENTIAL damages, whether arising from contract, tort, warranty, representation, instruction, defects, or from any other cause.

KAPPLER HEREBY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANT ABILITY OR FITNESS FOR A PARTICULAR PURPOSE. There are no warranties which extend beyond description on the face hereof.

The purchaser and all users are deemed to have accepted the terms of this Warranty, including its limitation of warranty and liability, which terms may not be varied by any verbal or written agreement.



SHOWER UNIT

→ Open carry case and lay out all parts.

→ Parts should include:

- Nylon Carry Case
- Yellow PVC Pad
- Zytron® Pool
- Shower Wand
- Shower Extension Holder
- Side Supports
- Corner Supports



SHOWER UNIT

- Place the protective yellow PVC pad onto assembly surface.
- Place the Zytron® Pool on the PVC pad.
- For protection during shipping, the Zytron® Pool is packaged inside out. The yellow should face up, the white is the bottom of the basin.



SHOWER UNIT

→ After righting the pool (turning over with the yellow facing up), place the four long side supports into the side openings of the pool.



SHOWER UNIT

→ Connect the four corner supports to the side supports to form a freestanding pool.



→ To install the shower wand, remove one corner support cap.



SHOWER UNIT

→ Insert the shower extension into the open corner support.



SHOWER UNIT

→ Insert the shower wand into the groove on the top of the shower extension.



SHOWER UNIT

→ Completed shower



PUMP SELECTION GUIDE

→ Empty your Zytron® pool after decontamination shower with our handy pump kits (sold separately)

- Complete, easy-to-use pump system transfers liquids from sumps, bladders and containers
- Internal pump parts are made of chemical-resistant Viton
- Manual, self-priming diaphragm pump can be used anywhere
- Hoses are made of nylon-reinforced PVC to prevent collapse while pumping
- Quick-connect hose fittings between pump and wands
- Removable filter system protects pump by cleaning debris from fluids
- Pumps up to 5 gallons per minute
- Bracket handle provides secure grip and hold-down for easy operation



Ex. Manual Pump Kit (DRM635)

**See supplement
“New Pig Pump
Selection Guide” to
learn which pump
is suitable or click here:
[PIG Pump Selection Guide](#)**



THANK YOU

