

Chemical Compatibility Guide for: SHOWA 7705PFT Disposable Nitrile Gloves

The guide on the following page(s) was provided by the supplier. New Pig Corporation assumes no responsibility, obligation, or liability in conjunction with the use or misuse of the information.



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: **1-800-468-4647**

Europe: **+31 (0)76 596 92 50**

China: **+86-21-400 921 5178**

PIG, PIG logo are registered trademarks in USA and other countries. See tm.newpig.com

UK: **0800 919 900**

Outside North America: **+1-814-684-0101**



7705PFT

Material Nitrile LENGTH 9.5 in. / 240mm

CHEMICAL PERMEATION

| CHEMICAL NAME | CAS NUMBER | BDT | |
|-----------------------------|------------|------------------|-------------------|
| | | TTL ASTM F739 | INT ASTM F1383 |
| Formaldehyde 37% | 50-00-0 | >480 | >240 |
| 2-Hydroxypropionic acid 85% | 50-21-5 | >480 | >240 |
| Carbon Tet | 56-23-5 | 1-5 | 1-5 |
| 1,2-Propanediol | 57-55-6 | >480 | >240 |
| Diethyl Ether | 60-29-7 | <1 | 1-5 |
| Aminobenzene | 62-53-3 | <1 | <1 |
| Ethanol | 64-17-5 | 6-10 | >10 |
| Formic Acid | 64-18-6 | <1 | 1-5 |
| Formic Acid 90% | 64-18-6 | <1 | 1-5 |
| Acetic Acid 84% | 64-19-7 | >10 | >30 |
| Methanol | 67-56-1 | 1-5 | 1-5 |
| 2-Propanol | 67-63-0 | >10 | >60 |
| 2-Propanone | 67-64-1 | <1 | 1-5 |
| Chloroform | 67-66-3 | <1 | <1 |
| Dimethylsulfoxide (DMSO) | 67-68-5 | >10 | >60 |
| Dimethyl Formamide | 68-12-2 | <1 | 1-5 |
| n-Propanol | 71-23-8 | 6-10 | >10 |
| Butanol | 71-36-3 | >10 | >30 |
| Alcohol, Amyl | 71-41-0 | >10 | >30 |
| Benzene | 71-43-2 | <1 | <1 |
| 1,1,1-Trichloroethane | 71-55-6 | <1 | <1 |
| Iodide, Methyl | 74-88-4 | <1 | <1 |
| ETHYLAMINE 70% | 75-04-7 | <1 | <1 |
| Acetonitrile | 75-05-8 | 1-5 | >10 |
| Acetaldehyde | 75-07-0 | <1 | 1-5 |
| Chloride, Methylene | 75-09-2 | <1 | 1-5 |

| | | | |
|---------------------------------------|----------|------|------|
| Bromoform | 75-25-2 | <1 | <1 |
| 1,1-Dichloroethene | 75-35-4 | <1 | <1 |
| Nitromethane | 75-52-5 | <1 | 1-5 |
| 1,2-Epoxypropane | 75-56-9 | <1 | 1-5 |
| Tetramethylammonium Hydroxide 25% | 75-59-2 | >120 | >240 |
| 1,1,2-Trichloro-1,2,2-trifluoroethane | 76-13-1 | 1-5 | 6-10 |
| Dimethyl Sulfate | 77-78-1 | 6-10 | >10 |
| Citric Acid 30% | 77-92-9 | >480 | >240 |
| 2-Butanol | 78-83-1 | >30 | >120 |
| 2-Butanone | 78-93-3 | <1 | 1-5 |
| Ethylene, Trichloride | 79-01-6 | <1 | <1 |
| 2-Propeneamide(s) 99% | 79-06-1 | >120 | >240 |
| 2-Propeneamide 50% | 79-06-1 | >120 | >240 |
| Acetate, Methyl | 79-20-9 | <1 | 1-5 |
| PERACETIC ACID 39% | 79-21-0 | 1-5 | 6-10 |
| Nitro Propane | 79-46-9 | <1 | <1 |
| Methacrylate, Methyl | 80-62-6 | <1 | 1-5 |
| DBP | 84-74-2 | >60 | >120 |
| Vinyl Pyrrolidinone | 88-12-0 | <1 | <1 |
| Biphenyl 27% | 92-52-4 | <1 | <1 |
| Dichlorobenzene O- | 95-50-1 | <1 | <1 |
| 2-Aminotoluene | 95-53-4 | 1-5 | 1-5 |
| 1,2,4 - Trimethyl Benzene 98% | 95-63-6 | 1-5 | >10 |
| Butanone Oxime | 96-29-7 | >10 | >30 |
| 2-Ethylbutyl alcohol | 97-95-0 | <1 | 1-5 |
| 2-Furaldehyde | 98-01-1 | <1 | 1-5 |
| Butyl Toluene, p-Tert | 98-51-1 | >10 | >30 |
| (1-Methylethyl)benzene | 98-82-8 | 1-5 | 1-5 |
| Cyclohexyldimethylamine | 98-94-2 | 1-5 | >10 |
| Nitrobenzene | 98-95-3 | <1 | 1-5 |
| Benzene, Ethyl | 100-41-4 | <1 | <1 |
| Benzene, Vinyl | 100-42-5 | <1 | 1-5 |
| Alcohol, Benzyl | 100-51-6 | <1 | <1 |
| Benzaldehyde | 100-52-7 | 1-5 | 6-10 |
| 4,4-Methylenedianiline | 101-77-9 | 1-5 | >10 |
| Oxybisbenzene,1,1- (Dowtherm) 73% | 101-84-8 | <1 | <1 |
| 2,2',2''-Nitrilotriethanol | 102-71-6 | 6-10 | >30 |

| | | | |
|---|----------|------|------|
| Methyl Isobutyl Ketoxime | 105-44-2 | >480 | >240 |
| Dimethylpiperazine | 106-58-1 | 6-10 | >10 |
| 1,2-Dichloroethane | 107-06-2 | <1 | 1-5 |
| Acrylonitrile | 107-13-1 | <1 | <1 |
| 1,2-Diaminoethane 99% | 107-15-3 | <1 | 1-5 |
| 2-Propen-1-ol | 107-18-6 | <1 | 1-5 |
| 1,2-Ethanediol | 107-21-1 | >480 | >240 |
| Methyl Propyl Ketone | 107-87-9 | <1 | 1-5 |
| 1-methoxy-2-propanol | 107-98-2 | 6-10 | >10 |
| Acetate, Vinyl | 108-05-4 | 1-5 | 1-5 |
| 2-Pentanone, Methyl- | 108-10-1 | 1-5 | 1-5 |
| Acetate, Isopropyl | 108-21-4 | 1-5 | 1-5 |
| PROPYLENE GLYCOL MONOMETHYL ETHER ACETATE | 108-65-6 | 1-5 | 6-10 |
| 2,6-Dimethyl-4-Heptanone | 108-83-8 | >10 | >60 |
| Benzene, Methyl | 108-88-3 | <1 | 1-5 |
| Benzene Chloride | 108-90-7 | <1 | 1-5 |
| Cyclohexanol | 108-93-0 | >60 | >240 |
| Cyclohexanone | 108-94-1 | 1-5 | 1-5 |
| Carbolic Acid 89% | 108-95-2 | 1-5 | >10 |
| Dimethyl Propaneamide, N,N' | 109-55-7 | 1-5 | 6-10 |
| Acetate, Propyl | 109-60-4 | 1-5 | 1-5 |
| Pentane | 109-66-0 | 1-5 | >10 |
| 1-Aminobutane | 109-73-9 | <1 | <1 |
| DEA | 109-89-7 | <1 | 1-5 |
| Diethylene Oxide | 109-99-9 | <1 | 1-5 |
| Hexane | 110-54-3 | >10 | >30 |
| 2-Ethoxyethanol | 110-80-5 | <1 | 1-5 |
| Cyclohexane | 110-82-7 | 6-10 | >30 |
| PYRIDINE | 110-86-1 | <1 | 1-5 |
| Diethylene oximide | 110-91-8 | <1 | <1 |
| 1,5-Pentanedial 50% | 111-30-8 | >30 | >60 |
| 2,2-iminodiethanol | 111-42-2 | >10 | >60 |
| Diethylene Glycol | 111-46-6 | >120 | >240 |
| 2-Butoxyethanol | 111-76-2 | 6-10 | >30 |
| n-Octanol | 111-87-5 | >480 | >240 |
| Ethylene Glycol Monoethyl Ether | 112-25-4 | >10 | >60 |
| Oleic Acid 98% | 112-80-1 | >480 | >240 |

| | | | |
|---|-----------|------|------|
| 1,2,4-Trichlorobenzene | 120-82-1 | <1 | <1 |
| 2,4-Dinitrotoluene 40% | 121-14-2 | 1-5 | 1-5 |
| TRIETHYLAMINE | 121-44-8 | 6-10 | >30 |
| 4-Hydroxy-4-methyl-2-pentanone | 123-42-2 | <1 | <1 |
| 3-Methyl-1-butanol | 123-51-3 | 1-5 | 1-5 |
| Butyl Acetate | 123-86-4 | <1 | <1 |
| 1,4-Dioxane | 123-91-1 | 1-5 | 6-10 |
| 3-Methylbutyl Ethanoate | 123-92-2 | <1 | 1-5 |
| PERC | 127-18-4 | 6-10 | >10 |
| Dimethylacetamide N,N- | 127-19-5 | 1-5 | 6-10 |
| Butyl Acrylate | 141-32-2 | 1-5 | 1-5 |
| 2-Aminoethanol | 141-43-5 | 6-10 | >10 |
| Ethyl Acetate | 141-78-6 | <1 | 1-5 |
| Heptane | 142-82-5 | >30 | >60 |
| Butoxytriglycol | 143-22-6 | 6-10 | >10 |
| OXALIC ACID (s) 99% | 144-62-7 | >480 | >240 |
| NINHYDRIN | 485-47-2 | >480 | >240 |
| 2,2,4-Trimethyl Pentane | 540-84-1 | >60 | >240 |
| Butyl Ethylene | 592-41-6 | <1 | <1 |
| Amyl Acetate | 628-63-7 | <1 | 1-5 |
| Methyl Pyrrolidone, N- | 872-50-4 | 1-5 | 6-10 |
| 2-Bromoethyl Acetate | 927-68-4 | 1-5 | 6-10 |
| Glyphosate Roundup 95% | 1071-83-6 | >480 | >240 |
| 3,8-Diamino-5-ethyl-6-phenylphenanthridinium bromide 5% | 1239-45-8 | >480 | >240 |
| Caustic Potash 45% | 1310-58-3 | >480 | >240 |
| Caustic Soda 50% | 1310-73-2 | >480 | >240 |
| Cresols | 1319-77-3 | <1 | <1 |
| Divinyl Benzene | 1321-74-0 | 1-5 | >10 |
| dimethyl benzene | 1330-20-7 | 1-5 | 1-5 |
| Chromic Acid Solution 50% | 1333-82-0 | <1 | <1 |
| Ammonia Solution 29% | 1336-21-6 | 6-10 | >30 |
| Methyl-Tert-Butyl Ether | 1634-04-4 | <1 | <1 |
| Dibutyl phenyl phosphate | 2528-36-1 | >10 | >60 |
| 2-Propoxyethanol | 2807-30-9 | 6-10 | 6-10 |
| Butoxypropanol | 5131-66-8 | 6-10 | >10 |
| D-Limonene | 5989-27-5 | 6-10 | >10 |
| 2,2'-dimorpholinodiethylether | 6425-39-4 | 1-5 | >10 |

| | | | |
|--------------------------------|------------|------|------|
| Hydrochloric Acid 37% | 7647-01-0 | >480 | >240 |
| Hydrochloric Acid 10% | 7647-01-0 | >480 | >240 |
| Phosphoric Acid 85% | 7664-38-2 | >480 | >240 |
| Hydrofluoric Acid 48% | 7664-39-3 | 6-10 | >10 |
| Sulfuric Acid 70% | 7664-93-9 | >60 | >240 |
| Battery Acid 47% | 7664-93-9 | >480 | >240 |
| Bleach: Sodium Hypochlorite 6% | 7681-52-9 | >480 | >240 |
| Nitric Acid 23% | 7697-37-2 | >120 | >240 |
| Nitric Acid 70% | 7697-37-2 | 1-5 | 6-10 |
| Hydrogen Peroxide 30% | 7722-84-1 | >480 | >240 |
| Hydroxylamine 50% | 7803-49-8 | >480 | >240 |
| Gasoline (unleaded) | 8006-61-9 | 1-5 | 1-5 |
| Fir Oil | 8006-64-2 | >30 | >120 |
| Kerosene | 8008-20-6 | 6-10 | >10 |
| Ligroin | 8032-32-4 | 6-10 | >30 |
| Dry Cleaning Mineral Spirits | 8052-41-3 | >120 | >240 |
| Ammonium Fluoride 40% | 12125-01-8 | >480 | >240 |
| 2-Chloro-2-Oxoethyl Acetate | 13831-31-7 | 1-5 | 6-10 |
| Fluoboric Acid 49% | 16872-11-0 | 6-10 | >30 |
| Antimony Tributylate 95% | 53856-17-0 | >120 | >240 |
| Dry cleaning safety solvent | 64475-85-0 | >480 | >240 |
| Diesel Fuel | 77650-28-3 | >480 | >240 |

BDT=BREAKTHROUGH DETECTION TIME

THE LEVEL (0 TO 6) INDICATES THE TIME REQUIRED FOR DIFFERENT CHEMICALS TO PERMEATE THROUGH THE GLOVE.

TTL : TOTAL IMMERSION CHEMICAL PERMEATION BREAKTHROUGH TIME.

INT : INTERMITTENT CONTACT CHEMICAL PERMEATION BREAKTHROUGH TIME, ONE MINUTE IMMERSION OUT OF EVERY TEN, REPEATEDLY.

Warranty Limitations and Disclaimer Use

This information is provided solely as a convenience to help you evaluate our gloves in the end-user's particular application. It is the responsibility of the purchaser and/or user to determine the level of toxicity of the materials to be handled and to select the proper glove suitable for a particular application. The information provided reflects laboratory performance of gloves under carefully controlled conditions. SHOWA makes no guarantee of results and assumes no obligation or liability in connection with this information.