

Chemical Compatibility Guide for: North[®] Silvershield[®]/4H[®] Products

The guide on the following page(s) was provided by the supplier. New Pig Corporation assumes no responsibility, obligation, or liability in conjunction with the use or misuse of the information.



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: **1-800-468-4647**

Europe: **+31 (0)76 596 92 50**

China: **+86-21-400 921 5178**

PIG, PIG logo are registered trademarks in USA and other countries. See tm.newpig.com

UK: **0800 919 900**

Outside North America: **+1-814-684-0101**



Silver Shield®/4H® Chemical Protection Guide

A comprehensive listing of Permeation Rates and Breakthrough Times for North Silver Shield®/4H® Hazardous Chemical Gloves, Aprons, Sleeves and Booties against 280 Chemical Contaminants in two temperatures.

TEST PROCEDURE

Chemical testing as per ASTM Standard F 739-91.

Detection limit: 0.1 µg / cm² / min.

Chemical testing as per EN 374: CE-0120.

KEY TO BREAKTHROUGH AND PERMEATION RATE

NT - Not Tested

NC - Not Calculated

C - Known or suspected Carcinogen

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)	
		Break-Through Time minutes	Permeation Rate µg / cm ² / minute	Break-Through Time minutes	Permeation Rate µg / cm ² / minute
ACCUMIXR (mixture) N-Alkyl Dimethyl Benzyl Amm. Chloride	68391-01-5				
N-Alkyl Dimethyl Ethylbenzyl Amm. Chloride Water	68956-79-6 7732-18-5	> 240		NT	
Ethyl Alcohol	64-17-5				
Acetaldehyde	75-07-0	> 240		NT	
Acetic Acid 100%	64-19-7	> 480		53	2.4
Acetic Anhydride	108-24-7	> 480		> 240	
Acetone	67-64-1	> 1440		> 240	
Acetone/Petrol 1:1	67-64-1 8032-32-4	9	NC	3	NC
Acetone/Toluene/ Methylated Spirit/ Conc. Ammonia 2 : 1 : 1 : 1	67-64-1 108-88-3 — 7664-41-7	190	NC	40	NC

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)		
		Break-Through Time minutes	Permeation Rate µg / cm ² / minute	Break-Through Time minutes	Permeation Rate µg / cm ² / minute	
Acetone/Water 20:80	67-64-1	> 240		> 240		
Acetonitrile	75-05-8	> 1440		> 240		
Acetonitrile 25% in water	75-05-8	> 240		> 240		
Acetophenone	98-86-2	> 480		> 240		
Acrolein	107-02-8	> 480		> 240		
Acrylamide 15% in MEK	79-06-1 78-93-3	> 240		> 240		C
Acrylamide Mixture n-n' methylenebisacrylamide	79-06-1 110-26-9	> 240		> 240		
Acrylate UV Lacquer (ethylacetate/butylacetate)	—	> 240		> 240		
Acrylic Acid	79-10-7	> 240		> 210	NC	
Acrylonitrile	107-13-1	> 480		> 240		C
AeroShell Fluid 4	—	> 240		> 240		
Allyl chloride	107-05-1	> 240		> 240		
Allylamine (propyleneamine)	107-11-9	15	NC	NT		
Ammonia Water 2N	7664-41-7	110	NC	40	NC	
Ammonia Water 25%	7664-41-7	> 240		30	NC	
Ammonium Flouride 34%	12125-01-8	> 240		> 240		
Ammonium Hydroxide (29, 1 w/w%) in water	1336-21-6	> 240		> 240		
Aniline	62-53-3	> 1440		> 240		
BENLATER (Benomyl)	17804-35-2	> 240		NT		
Benzaldehyde	100-52-7	> 480		> 240		
Benzene	71-43-2	> 1440		> 240		C
3, 3', 4, 4' Benzophenone Tetracarboxylic Dianhydride	2421-28-5	> 240		NT		
Benzyl Alcohol	100-51-6	> 480		NT		
Benzyl Chloride	100-44-7	> 480		> 240		
Benzyl Cyanide	140-29-4	> 240		> 240		
n-Benzyl Dimethylamine	103-83-3	> 240		NT		
Bisphenol A diglycidyl Ether (EPOXY) 50% in MEK	1675-54-3 78-93-3	> 480		> 240		
Bromoacetic Acid	79-08-3	> 240		> 240		
Bromoacetonitrile	590-17-0	> 240		> 240		
2-Bromoacetophenone	70-11-1	> 240		> 240		
1-Bromoethylethyl Carbonate	89766-09-6	> 240		> 240		
1, 4-Butanediol diglycidyl ether 50% in MEK	2425-79-8 78-93-3	> 240		> 240		
n-Butanol	71-36-3	> 480		> 240		
sec-Butanol	78-92-2	> 480		> 240		
tert-Butanol	75-65-0	> 480		> 240		
n-Butyl Acetate	123-86-4	> 480		> 240		
Butyl Acrylate	141-32-2	> 480		> 240		
2-Butoxyethanol (butyl glycol)	111-76-2	> 240		> 240		
tert-Butyl Hydroperoxide	75-91-2	> 240		NT		
Butyraldehyde	123-72-8	> 480		> 240		
Carbon Disulfide	75-15-0	> 1440		> 240		
Carbon Tetrachloride	56-23-5	> 480		> 240		
Chlorine	7782-50-5	> 240		NT		
Chloroacetone	78-95-5	> 240		> 240		
2-Chloroethanol	107-07-3	> 240		> 240		
Chloroform	67-66-3	> 1440		> 240		C
Chloroform/ tert. Butanol 80 : 20	67-66-3 75-65-0	> 240		> 8		C

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)		
		Break-Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute	Break-Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute	
Chloroform w/30% Methanol	67-66-3 67-56-1	> 240		> 240		C
3-Chloropropene	107-05-1	> 240		NT		
CLOVA THINNER #19® Toluene 50% MEK 15% Methanol 15% 2-Butoxyethanol 10% Ethyl Acetate 10%	108-88-3 78-93-3 87-56-1 111-76-2 141-78-6	> 240			NT	
Chromic Acid 50%	1333-82-0	> 240		> 240		
Chromic Acid/ Sulphuric Acid	1333-82-0 7664-93-9	> 240		> 240		
Coal Tar/ Benzene 1:1	— 71-43-2	> 240		> 240		C
Corrosive Fluid Dyrupe 49685	—	102	NC	20	NC	
Creosote	8001-58-9	> 240		> 240		C
p-Cresol 50% in MEK	106-44-5 78-93-3					
Cyclohexane	110-82-7	> 480		> 240		
Cyclohexanol	108-93-0	> 480		> 240		
Cyclohexanone	108-94-1	> 480		> 240		
Cyclohexylamine 32% Morpholine 8% Water 60%	108-91-8 110-91-8	> 240	NT			
Cyclopentanone	120-92-3	> 240		> 240		
CYMBUSHR (Cypermethrin)	52315-07-8	> 240		NT		
DEEP WOODS OFF® (Mixture) N, N-Diethyltoluamide Ethanol	134-62-3 64-17-5	> 240		NT		
DEGALAN S 309® (Mixture)	—	> 240		NT		
DEGALAN S 696® (Mixture)	—	> 240		NT		
Diacetone alcohol	123-42-2	> 240		> 240		
4, 4'-Diaminodiphenyl- methane (MDA) 50% in MEK	537-65-5 78-93-3	> 480		> 240		C
1, 2-Dibromoethane	106-93-4	> 480		NT		
Dibutyl Ether	142-96-1	> 480		NT		
Di-n-Butyl Phthalate	84-74-2	> 240		> 240		
1, 3-Dichloro-2-Butene	926-57-8	> 240		NT		
1, 2-Dichlorobenzene	95-50-1	> 240		> 240		
1, 2-Dichloroethane	107-06-2	> 240		> 240		C
1, 1-Dichloroethylene	75-35-4	> 420		> 420		
Dichloromethane 90% Isopropyl Alcohol 10%	75-09-2 67-63-0	> 480		> 240		
Diethanolamine 50% in Water	111-42-2	> 240		> 240		
n, n-Diethylacetamide	685-91-6	> 480		> 240		
Diethylamine	109-89-7	> 60	NC	6	NC	
Diethylenetriamine	111-40-0	> 240		NT		
Diethyl Ether	60-29-7	> 480		> 240		
N, N Diethyl nitrosoamine	55-18-5	> 240		NT		

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)	
		Break-Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute	Break-Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute
Diethylphthalate (Phthalic acid diethylester)	84-66-2	> 240		NT	
Diisobutyl ketone	108-83-8	> 240		> 240	
Dimercaptothiodiazole 10% in Butyldioxotol/MEK 1:1	1072-71-5	> 240		> 240	
N, N Dimethyl- Cyclohexylamine	98-94-2	> 480		NT	
Dimethylmercury	593-74-8	60		NT	
Dimethyl Sulfoxide	67-68-5	> 480		194	2.2
N, N-Dimethylacetamide	127-19-5	> 240		> 240	
2 – Dimethylamino - Ethanol	108-01-0	350		NT	
N, N-Dimethylaniline	121-69-7	> 240		> 240	
Dimethylethanolamine	108-01-0	> 240		> 240	
Dimethylethylamine	598-56-1	9	NC	2	NC
Dimethylformamide	68-12-2	> 1440		> 240	
Dimethylsulphate	77-78-1	> 240		> 240	C
Dinol	—	> 240		NT	
Dinoseb (47, 6% in Xylene)	88-85-7 1330-20-7	> 240		> 240	
1, 4-Dioxane	123-91-1	> 480		> 240	C
Dipentene (limonen)	138-86-3	> 480		36	
2, 3-Diphenyl-2-cyclopropen- 1-one 2% Acetone w/10% Propyleneglycol	886-38-4 67-64-1 57-55-6	> 240		> 240	
Di-(2-ethylhexyl) phthalate	117-81-7	> 240		> 240	C
Diquat Dibromide	85-00-7	> 240		> 240	
Dodecane	112-40-3	> 480		> 240	
Dynasylan BH-N	—	> 480		NT	
Epichlorohydrin	106-89-8	> 240		> 240	C
EPOXIDHARZ-KLEBSTOFF® Schüco art. 298011 A	—	> 240		> 240	
EPOXIDHARZ-KLEBSTOFF® Schüco art. 298011 B	—	> 240		> 240	
Ethanol 96%	64-17-5	> 480		> 240	
Ethanolamine	141-43-5	> 480		> 240	
Ethidium Bromide	1239-45-8	> 480		NT	
2-(2-Aminoethoxy)ethanol	929-06-6	> 240		> 240	
2-Ethoxy-1-Propanol	19089-45-5	> 240		> 240	
Ethyl Acetate	141-78-6	> 1440		> 240	
Ethyl Acrylate	140-88-5	> 240		> 240	C
Ethyl Benzene	100-41-4	> 480		> 480	
Ethyl Glycol	110-80-5	> 240		> 240	
Ethyl Glycol Acetate	111-15-9	> 240		> 240	
Ethylendiamine	107-15-3	92	NC	47	NC
Ethylene Glycol	107-21-1	> 240		> 240	
Ethylene Oxide	75-21-8	> 240		NT	
Extraction petrol 80/110	—	> 240		> 240	
Fluoroboric solution: Hydrofluoric acid Boric acid Nitric acid	7664-39-3 10043-35-3 7697-37-2	> 240		NT	
Formaldehyde	50-00-0	> 240		> 240	
Formaldehyde 37% w/10% Methanol	50-00-0 67-56-1	> 480		> 240	C

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)		
		Break-Through Time minutes	Permeation Rate µg / cm ² / minute	Break-Through Time minutes	Permeation Rate µg / cm ² / minute	
Formic Acid 98-100%	64-18-6	120	NC	60	NC	
Freon 113	76-13-1	> 240		> 240		
Furfural	98-01-1	> 480		> 240		
Furfuryl Alcohol	98-00-0	> 480		> 240		
GammaButyrolactone Merck 801661	96-48-0	> 480		NT		
GLANCER (mixture)	—	> 240		NT		
Glutardialdehyde 2% in Water	111-30-8	> 240		> 240		
Glutardialdehyde 25% in Water	111-30-8	> 240		> 240		
Glycerol	56-81-5	> 240		> 240		
Glycerol Monothioglycolate 80%	30618-84-9	> 240		NT		
Glycerolpropoxy-triacrylate	—	> 240		> 240		
GLUMA	—	> 240		NT		
Heptane	142-82-5	> 480		> 240		
1, 1, 1, 3, 3, 3 – Hexamethyl Disilazane	999-97-3	> 240		> 240		
n-Hexane	110-54-3	> 1440		> 240		
Hexane/Benzene 9:1	110-54-3 71-43-2	> 240		> 240		C
Hydraulic oils	—	> 240		> 240		
Hydrazin 80%	7803-57-8	> 240		> 240		C
Hydrocarbon Mixture (K-Blend)	—	> 240		NT		
Hydrochloric Acid 2N	7647-01-0	> 240		> 240		
Hydrochloric Acid 37%	7647-01-0	> 240		NT		
Hydrochloric Acid 37% /Nitric Acid 65% 3:1	7647-01-0 7697-37-2	> 240		> 240		
Hydrofluoric Acid 10%	7664-39-3	> 240		120	NC	
Hydrofluoric Acid 30%	7664-39-3	> 240		120	NC	
Hydrofluoric Acid 40%	7664-39-3	> 240		120	NC	
Hydrofluoric Acid 49%	7664-39-3	> 240		30	NC	
Hydrofluoric Acid 70%	7664-39-3	60	NC	30	NC	
Hydrofluoric Acid 100%	7664-39-3	15				
Hydrogen Cyanide	74-90-8	> 240		NT		
Hydrogen Peroxide 30%	7722-84-1	> 240		NT		
Hydroquinone 33% in Ethanol	123-31-9 64-17-5	> 240		> 240		
2-Hydroxy-Methacrylate (HEMA)	868-77-9	> 240		NT		
2-Hydroxyethyl-N, N, N- Trimethyl ammonium Hydroxid	—	> 240		> 240		
2-Hydroxyethyl Acrylate	818-61-1	> 240		> 240		
IMRON 192R S/Hexamethylene Diisocyanate 37%	—	> 240		NT		
Isobutanol	78-83-1					
Isopentylalcohol/ Chloroform 1:24	123-51-3 67-66-3	176	NC	40	NC	C
Isophorone	78-59-1	> 240		> 240		
Isopropanol	67-63-0	> 240		> 240		
Isopropyl Nitrate	1712-64-7	> 240		NT		
Jet Fuel (Jet A-1/Shell)	—	> 240		> 240		

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)		
		Break-Through Time minutes	Permeation Rate µg / cm ² / minute	Break-Through Time minutes	Permeation Rate µg / cm ² / minute	
KOVAC'S INDOLREAGENT®	—	> 240		> 240		
Lubricat. Oil, DTE 25	—	> 240		> 240		
Malathion	121-75-5	> 240		NT		
2-Mercaptoethanol	60-24-2	> 240		> 240		
Mercury (Hg)	7939-97-6	> 480		NT		
Methacrylic Acid	79-41-4	> 480		> 240		
Methacrylic Adhesive	—	> 240		> 240		
Methanol	67-56-1	> 480		30	1.6	
1-Methoxy-2-Propanol	107-98-2	> 240		> 240		
1-Methoxy-2-Propylacetate	108-65-6	> 240		> 240		
2-Methoxyethanol	109-86-4	> 240		> 240		
2-Methoxyethyl-Acetate	110-49-6	> 240		> 240		
Methyl Acetate	79-20-9	> 480		> 240		
Methyl Ethyl Ketone (MEK)	78-93-3	> 1440		> 240		
Methyl Ethyl Ketone/ Toluene 1:1	78-93-3 108-88-3	114	NC	9	NC	
5-Methyl-2-Hexanone (Methyl Isoamyl Ketone)	110-12-3	> 480		> 240		
Methyl Isobutyl Ketone	108-10-1	> 480		> 240		
Methyl Methacrylate	80-62-6	> 480		> 480		
5-Methyl-5-Norbornene 2, 3-Dicarboxylic Anhydride (Methyl Nadic Anhydride)	25134-21-8	> 240		NT		
Methyl-pentyl-ketone	110-43-0	> 240		> 240		
Methyl n-propyl Ketone (2-Pentanone)	107-87-9	> 480		NT		
N-Methyl-2-Pyrrolidone	872-50-4	> 240		> 240		
Methyl-tert-Butyl Ether	1634-04-4	> 480		NT		
Methyl Trichlorosilane	75-79-6	> 240		NT		
Methylamine 40%	74895	> 240		80	1.3	
4, 4' -Methylene bis (MOCA, MBOCA or MBOCHA) (2-Chloroaniline) 50% in Acetone	101-14-4 67-64-1	> 240		NT		C
Methylene Bisphenyl- 4, 4-diisocyanate (MDI)	101-68-8	> 480		> 240		
Methylene Chloride	75-09-2	> 1440		> 240		C
4, 4' -Methylenedianiline 10% in Isopropyl alcohol	537-65-5 67-63-0	> 240		NT		
Methylenedianiline 50% in MEK (MDA)	537-65-5 78-93-3	> 480		NT		C
Methyliodide	74-88-4	123	NC	8	NC	
Mixture of: N-Methyl Pyrrolidone Butyrolactone Styrene	872-50-4 96-48-0 100-42-5	> 480		> 480		
Mixture of: Methylene Chloride 20% Trichlorethylene 20% Xylene 45% Mineral Spirits 15%	75-09-02 79-01-06 1330-20-7 8032-32-4	> 240		> 240		
Mixture of: MEK 66% Cyclohexanone 24% Toluene 10%	78-93-3 108-94-1 108-88-3	> 480		NT		

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)		
		Break-Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute	Break-Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute	
Mixture of: 1, 3-Phenylenediamine 30% Ethylacetate 70%	108-45-2 141-78-6	> 480		NT		
Mixture of: Toluene 50% Isopropylalcohol 25% Methylethylketone 25%	108-88-3 67-63-0 78-93-3	> 480		NT		
Morpholine	110-91-8	> 480		94	2.5	
Mustard Gas	505-60-2	> 1440		> 1440		C
N35091 Cleaning agent	—	> 480		NT		
N 39/3010 Thinner	—	> 480		NT		
Naphthalene 25% in Toluene	91-20-3	> 240		> 240		
1-Naphthylamine 25% in Isopropanol	134-32-7	> 240		> 240		
Nicotine	54-11-5	> 240		> 240		
Ninhydrin 4% in 2-Methoxyethanol	485-47-2	> 240		> 240		
Nitric Acid 2N	7697-37-2	> 480		> 240		
Nitric Acid 65%	7697-37-2	> 40		NT		
Nitric Acid 100% (red fuming)	7697-37-2	180	NC	60		
Nitrobenzene	98-95-3	> 1440		> 240		
2-Nitrobenzylbromide	3958-60-9	> 240		> 240		
4-Nitrodiphenylamine	119-75-5	> 240		> 240		
Nitroethane	79-24-1	> 480		> 240		
Nitroglycerol	55-63-0	> 240		NT		
Nitroglycol	628-96-6	> 240		NT		
Nitromethane	75-52-5	> 480		> 240		
2-Nitropropane	79-46-9	> 240		> 240		C
O-Toluidine	95-53-4	> 480		> 480		
Orthocid 83	133-06-2	> 240		NT		
KVK PARATHION 35R	—	> 240		NT		
PAINTSTRIPPER D23® 30% in Dichloromethane	—	200	NC	NT		
PCB 12/60 Chloric	1336-36-3	> 240		> 240		C
Pentane	109-66-0	> 480		> 240		
Perchloric Acid 70%	760 1-90-3	> 240		> 240		
Perchloroethylene	127-18-4	> 480		> 480		C
PERGA KAN® Domo/Master A/S - DK	—	> 240		> 240		
PERMA FLUID "MICA" (8% Ammonia Thioglycolate)	—	> 240		> 240		
Petroleum (Gasoline) 95 & 96 unleaded/leaded	93572-29-3	> 240		> 240		
Petroleum (Gasoline) (Shell specialty)	—	> 240		> 240		
80% Petroleum 20% n-Methyl-2-pyrrolidon	— 872-50-4	> 240		> 240		
Petroleum ether 80/110	8032-32-4	> 480		> 480		
Phthalic Acid Anhydride	85-44-9	> 240		NT		
Phenol 50% in MEK	108-95-2 78-93-3	> 240		> 240		

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)		
		Break-Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute	Break-Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute	
Phenol/Isopentanol/ Chloroform 25:1:24	108-95-2 123-51-3 67-66-3	130	NC	70	NC	C
Phosphoric Acid 85%	766-38-2	> 240		> 240		
Phosphorylic Chloride	10025-87-3	> 240		> 240		
PHOTO RESIST 1450® (INMOS)	111-15-9 1330-20-7 123-86-4	> 240		> 240		
3-Picolyl Chloride Hydrochloride 25% in water	6959-48-4	> 240		> 240		
3-Picolyl Chloride Hydrochloride/ Acetonitrile/water 4:3:9	6959-48-4 75-05-8	> 240		> 240		
4-Picolylchloride hydrochloride	1822-51-1	> 240		> 240		
Polyethyleneglycol	25322-68-3	> 480		NT		
Polyol mixture	—	> 480		NT		
Posistrip LE, (INMOS)	110-91-8 96-48-0 872-50-4	> 240		> 240		
Potassium Hydroxide 50%	1310-58-3	> 240		> 240		
Potass. Permanganate Solution, Saturated	7722-64-7	> 240		NT		
PRAMITOLR	1610-18-0	> 240		NT		
PRO STRIPR (Mixture): Monoethanolamine Glycol Ether Isopropanol Polyoxyethylene Phenylether Phosphate Ammonium Hydroxide	141-43-5 111-76-2 67-63-0 39464-70-5 1336-21-6	> 240		NT		
1-Propanol	71-23-8	> 240		> 240		
Propiophenone	93-55-0	> 240		> 240		
Propyl Acetate	109-60-4	> 480		> 240		
Propylene Glycol	57-55-6	> 240		> 240		
Propylene Glycol Morioethyl Ether Acetate	19234-20-9	> 240		> 240		
1, 2-Propylene Oxide	75-56-9	> 480		NT		
1, 2-Propylene Oxide in Water	75-56-9	> 240		26	3.0	C
Propylamide 50% (Kerb 50®) 10% suspended in Water	23950-58-5	> 240		NT		
Pyridine	110-86-1	> 480		> 240		
PYROTEC HFD 46R	—	> 240		NT		
Quinoline	91-22-5	> 240		> 240		
REGLONER	85-00-7	> 240		NT		
830 RESIST STRIPPERR (INMOS)	929-06-6 872-50-4	> 240		> 240		
ROUNDUP® Glyphosat-isopropylamine derivate 450 g/l	38641-94-0	> 240		NT		
SADOFOS PRIMER® 17	—	> 240		> 240		
SADOFOS PRIMER® 513	—	> 240	64	NC		

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)	
		Break-Through Time minutes	Permeation Rate µg / cm ² / minute	Break-Through Time minutes	Permeation Rate µg / cm ² / minute
Silver Cyanide 4%	506-64-9	> 240		NT	
SKYDROL® (mix of Tributyl phosphate/ Dibutylphenolphosphate)	126-73-8	> 480		NT	
Sodium Hydroxide 2N	1310-73-2	> 1440		> 240	
Sodium Hydroxide 50%	1310-73-2	> 480		> 240	
Sodium Hydroxide 96-98%	1310-73-2	> 480		NT	
Sodium Hypochlorite 15% in Water	7681-52-9	> 240		> 240	
SOLMASTER® Methylene Chloride/Ethanol	—	> 240		> 240	
STAR THINNER 7040® Xylene/Butylglycol	1330-20-7 111-76-2	> 240		> 240	
Styrene	100-42-5	> 1440		> 240	
Sulphuric Acid 90%	7664-93-9	> 480		> 240	
Sulphuric Acid 93%	7664-93-9	> 1440		NT	
Sulphuric Acid 96% w.65% SO ₃ (oleum)	7664-93-9	120	NC	30	NC
Sulphuric Acid 2N	7664-93-9	> 240		> 240	C
Sulphuric Acid 96% Hydrogen Peroxide 30% 3:1	7664-93-9 7722-84-1	> 480		NT	
Tetrachloroethylene	127-18-4	> 1440		> 240	
Tetraethyl Orthosilicate	78-10-4	> 480		> 480	
Tetrafluoroboric Acid (HBF ₄) 35%	16872-11-0	> 240		NT	
Tetrahydrofuran	109-99-9	> 480		> 240	
Tetrahydrofuran 50% Toluene 50%	109-99-9 108-88-3	89	NC	NT	
Tetramethyl Ammonium Hydroxide in water	75-59-2	> 240		> 240	
Thioglycolic Acid	123-93-3	> 240		> 240	
Thiourea 7, 5% in 50% Ethanol	62-56-6 64-17-5	> 240		> 240	
Toluene	108-88-3	> 1440		> 240	
Toluene-2, 4-Diisocyanate TDI 40% in Xylene	584-84-9 1330-20-7	> 480		> 240	
Toluene Isopropanol 1:1	108-88-3 67-63-0	> 240		> 240	
Transformer Oil Nytro 10X, Nynäs/Oslo	—	> 240		> 240	
Transmission Oil Opel, Dextron GM 6137M	—	> 240		> 240	
Tributylphosphate	126-73-8	> 240		> 240	
1, 1, 1-Trichloroethane	71-55-6	> 480		> 240	C
1, 1, 1-Trichloroethane w. 3% 1, 4-Dioxane	71-55-6 123-91-1	> 240		> 240	
1, 1, 1-Trichloroethane /Ethanol/Turpentine amounts unknown	71-55-6 64-17-5 8006-64-2	> 240		NT	
1, 1, 1-Trichloroethane 73% Methylene Chloride 17% Dodecylbenzensulphohonacid 10%	71-55-6 75-02-9 2776-87-0	> 240		NT	
1, 1, 1-Trichloroethane/ Propyleneglycolmono- ethyletheracetate 3:1	71-55-6 19234-20-9	> 240		>240	
Trichloroethylene	79-01-6	> 1440		> 240	

Chemical	C A S Reg. No.	21° C (70° F)		35° C (95° F)	
		Break- Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute	Break- Through Time minutes	Permeation Rate $\mu\text{g} / \text{cm}^2 /$ minute
Triethanolamine 50% in Water	102-71-6	> 240		> 240	
Triethylenediamine	280-57-9	> 480		NT	
Triethyldiamine 25% in Water	280-57-9	> 240		220	NT
Triethylene Tetramine (TETA) 50% in MEK	112-24-3 78-93-3	> 240		> 240	
Trifluoroacetic Acid	76-05-1	> 240		> 240	
Triphosgene	32315-10-9	> 240		> 240	
Tripropylene glycol Diacrylate	42978-66-5	> 240		> 240	
TURCO 5092® (Stripping agent)	—	132	NC	28	NC
U-V RESIN 20074®	—	> 240		> 240	
Vinyl Acetate	108-05-4	> 480		> 240	
Vinyl Chloride 99%	75-01-4	> 480		> 480	
N-Vinylpyrrolidone	88-12-0	> 240		> 240	
White Spirit (Naphtha)	8052-41-3	> 480		> 240	
XYLAMON®	—	> 240		NT	
Xylene	1330-20-7	> 1440		> 240	
Xylene/Ethyl Glycol 1:1	1330-20-7, 110-80-5	> 240		> 240	

All product or corporate names listed as trademarks or registered trademarks are the property of their respective companies.