

Spring-Open Leak Diverter

Instructions

Step 1 — Unpack the hose and diverter assemblies

Remove the hose assembly from the front pocket of the yellow storage case. Then remove the diverter from the large pocket. Open the diverter slowly, holding it away from your face as the coiled spring steel frame pops open. Separate the large hooks that are nestled together. (fig. A)

Step 2 — Hang the diverter under the leak

Hang the diverter under the leak by attaching the four hooks to appropriate access points (beams, pipes, struts, etc.). Level and adjust to the desired length by lengthening or shortening the bungee cords and sliding the diverter into position.

NOTE: The oval Spring-Open Leak Diverter has extra grommets for additional bungees in case of unique hanging applications. (fig. B)

Step 3 — Attach the hose assembly

Click the quick-connect hose into the diverter nozzle and position the other end of the hose into the collection receptacle. (fig. C)



fig. A



fig. B



fig. C

Turn over for storage information



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: **1-800-468-4647**

Europe: **+31 (0)76 596 92 50**

PIG, PIG logo are registered trademarks in USA and other countries. See tm.newpig.com

UK: **0800 919 900**

Outside North America: **+1-814-684-0101**

501927 / 330060

Storage

A video showing how to fold the diverter unit for storage is available at newpig.com.

Step 1 — Prepare the diverter and hose assemblies

Disconnect quick-connect hose from diverter. Wipe dry the diverter unit and hose before storage. Coil the hose and cinch with the hook and loop band.

Step 2 — Prepare hooks and bungees

Secure the hooks on the diverter by nesting them together. Fit the bottom of one hook into the top crook of the other hook, then repeat with the other end. (fig. A) Slip the loop of the bungee over the hook tops and cinch closed. Shorten all bungee cords.

Step 3 — Fold the diverter

- A. Grasp opposite sides (3 o'clock and 9 o'clock) of the opened diverter with the palm of your left hand facing up (thumb pointing away from you) and the palm of your right hand facing down (thumb pointing toward you). (fig. B) Twist your wrists in opposite directions about ½ turn, as if you were wringing out a towel.
- B. As you twist, the diverter will begin to coil into a looped figure eight shape. (fig. C)
- C. Keeping your left hand stationary, keep twisting the right side and move your right hand inside and closer to the left, tucking the right loop into the left. As you do this, you will notice three loops forming. (fig. D)
- D. The middle loop will get sandwiched between the top loop and bottom loop.
- E. Keep tucking and adjusting until all the loops are about the same size and the diverter forms a neat package. (fig. E)

Step 4 — Pack the diverter and hose

Store the hose in the front pocket of the case, and the diverter in the larger pocket.



fig. A



fig. B



fig. C



fig. D



fig. E



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: **1-800-468-4647**

Europe: **+31 (0)76 596 92 50**

PIG, pig logo are registered trademarks in USA and other countries. See tm.newpig.com

UK: **0800 919 900**

Outside North America: **+1-814-684-0101**

501927 / 330060